

IMPORTANT! Please read all instructions before installing.

Thank you for purchasing a Shakespeare product. Before installing, please study the diagram and check parts supplied against those listed.

The 5187 Stainless Steel Ratchet Mount is a versatile, free-standing mount with a four-way ratchet design. It can be used for mounting to vertical or horizontal surfaces (deck or bulkhead) and to adjust to a slanted surface.

TOOLS REQUIRED:

- Drill with drill bit
- Pliers or wrench
- Screwdrivers - one for mounting bolt heads and a wide blade screw driver to tighten the mount's holding screw

INSTALLATION INSTRUCTIONS

Choose a mounting location according to the requirements of the antenna you are using.

1. Mark the locations for the four mounting holes using the mount's base as a template.
2. Drill the mounting holes. When drilling fiberglass, use a backup block of wood to reduce push-through surface damage.
3. Mount the antenna using stainless steel 1/4" bolts, washers lock washers, and nuts (412 Stainless Steel Mounting Hardware Kit sold separately), or other hardware (not supplied) that is suitable to the mounting surface.

IMPORTANT: If the thickness of the mounting surface is not adequate to support the antenna under stress, a wood or metal back-up plate (not supplied) should be placed under the deck during mounting installation (see illustration). When the boat is operated at high speed, it is recommended that the antenna be lowered, to prevent breakage or deck damage.

4. For a streamlined look, cable may be routed through the slot provided in the side of the mount. To preserve the mount's luster, apply auto wax or metal polish.

SUPPLIED PARTS:

- 1 Stainless Steel Mount

